

Calibrating Unit

New Standard Solution Report

Equipment

Alcotest 7110 MKIII-C
Location: PLAINSBORO TOWNSHIP PD
Serial No.: ARTL-0005
Calibration File No.: 00005
Calib. Date: 01/05/2005
Calib. No.: 00002
Certification File No.: 00006
Cert. Date: 01/05/2005
Cert. No.: 00001
Linearity File No.: 00007
Lin. Date: 01/05/2005
Lin. No.: 00001
Solution File No.: 00008
Soln. Date: 01/05/2005
Soln. No.: 00002
Sequential File No.: 00008
File Date: 01/05/2005

Calibrating Unit: WET
Control Solution %: 0.100%
Solution Control Lot: 04K008

Model No.: CU-34

Serial No.: DDUF S3-0064
Expires: 11/13/2006
Bottle No.: 0471

Function	Result %BAC	Time HH:MM	Temperature Simulator (°C)	Comment(s) or Error(s)
Ambient Air Blank	0.000%	15:17S		
Control 1 EC	0.099%	15:17S	34.0°C	*** TEST PASSED ***
Control 1 IR	0.098%	15:17S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	15:18S		
Control 2 EC	0.099%	15:18S	34.0°C	*** TEST PASSED ***
Control 2 IR	0.098%	15:18S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	15:19S		
Control 3 EC	0.098%	15:20S	34.0°C	*** TEST PASSED ***
Control 3 IR	0.098%	15:20S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	15:20S		

All tests within acceptable tolerance.

On this date, I installed the above indicated "NEW SOLUTION" in accordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Changed By:

Last Name: RUSSO

First Name: MATTEO

MI: B

Signature: Matteo Russo

Badge No.: 5204

Date: 01/05/2005

Calibrating Unit

New Standard Solution Report

Equipment	Alcotest 7110 MKIII-C	Serial No.:	ARTL-0005
Location:	PLAINSBORO TOWNSHIP PD		
Calibration File No.:	00005	Calib. Date:	01/05/2005
Certification File No.:	00006	Cert. Date:	01/05/2005
Linearity File No.:	00007	Lin. Date:	01/05/2005
Solution File No.:	00016	Soln. Date:	02/01/2005
Sequential File No.:	00016	File Date:	02/01/2005
Calibrating Unit:	WET	Model No.:	CU-34
Control Solution %:	0.100%	Serial No.:	DDUF S3-0064
Solution Control Lot:	04K008	Expires:	11/13/2006
		Bottle No.:	0873

Function	Result %BAC	Time HH:MM	Temperature Simulator (°C)	Comment(s) or Error(s)
Ambient Air Blank	0.000%	09:30S		
Control 1 EC	0.102%	09:31S	34.0°C	*** TEST PASSED ***
Control 1 IR	0.100%	09:31S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	09:32S		
Control 2 EC	0.099%	09:32S	34.0°C	*** TEST PASSED ***
Control 2 IR	0.099%	09:32S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	09:33S		
Control 3 EC	0.098%	09:34S	34.0°C	*** TEST PASSED ***
Control 3 IR	0.099%	09:34S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	09:35S		

All tests within acceptable tolerance.

On this date, I installed the above indicated "NEW SOLUTION" in accordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Changed By:

Last Name: BRESNEN

First Name: JOHN

MI: A

Signature: John J. Bresnen

Badge No.: 531

Date: 02/01/2005

Calibrating Unit New Standard Solution Report

Equipment	Alcotest 7110 MKIII-C	Serial No.: ARTL-0005
Location:	PLAINSBORO TOWNSHIP PD	
Calibration File No.:	00005	Calib. Date: 01/05/2005
Certification File No.:	00006	Cert. No.: 00002
Linearity File No.:	00007	Cert. Date: 01/05/2005
Solution File No.:	00020	Lin. Date: 01/05/2005
Sequential File No.:	00020	Lin. No.: 00001
		Soln. Date: 02/25/2005
		Soln. No.: 00004
		File Date: 02/25/2005
Calibrating Unit:	WET	Model No.: CU-34
Control Solution %:	0.100%	Serial No.: DDUF S3-0064
Solution Control Lot:	04K008	Expires: 11/13/2006
		Bottle No.: 0866

Function	Result %BAC	Time HH:MM	Temperature Simulator (°C)	Comment(s) or Error(s)
Ambient Air Blank	0.000%	20:42S		
Control 1 EC	0.101%	20:43S	34.0°C	*** TEST PASSED ***
Control 1 IR	0.099%	20:43S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	20:44S		
Control 2 EC	0.098%	20:44S	34.0°C	*** TEST PASSED ***
Control 2 IR	0.100%	20:44S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	20:45S		
Control 3 EC	0.098%	20:46S	34.0°C	*** TEST PASSED ***
Control 3 IR	0.100%	20:46S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	20:47S		

All tests within acceptable tolerance.

On this date, I installed the above indicated "NEW SOLUTION" in accordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Changed By:

Last Name: BRESNEN

First Name: JOHN

MI: A

Signature:



Badge No.: 531

Date: 02/25/2005

Calibrating Unit

New Standard Solution Report

Equipment Alcotest 7110 MKIII-C Serial No.: ARTL-0005
Location: PLAINSBORO TOWNSHIP PD
Calibration File No.: 00005 **Calib. Date:** 01/05/2005 **Calib. No.:** 00002
Certification File No.: 00006 **Cert. Date:** 01/05/2005 **Cert. No.:** 00001
Linearity File No.: 00007 **Lin. Date:** 01/05/2005 **Lin. No.:** 00001
Solution File No.: 00029 **Soln. Date:** 03/25/2005 **Soln. No.:** 00005
Sequential File No.: 00029 **File Date:** 03/25/2005

Calibrating Unit: WET **Model No.:** CU-34 **Serial No.:** DDUF S3-0064
Control Solution %: 0.100% **Expires:** 11/13/2006
Solution Control Lot: 04K008 **Bottle No.:** 0856

Function	Result	Time	Temperature	Comment(s)
	%BAC	HH:MM	Simulator (°C)	or Error(s)
Ambient Air Blank	0.000%	16:06S		
Control 1 EC	0.099%	16:07S	34.0°C	*** TEST PASSED ***
Control 1 IR	0.100%	16:07S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	16:08S		
Control 2 EC	0.096%	16:08S	34.0°C	*** TEST PASSED ***
Control 2 IR	0.099%	16:08S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	16:09S		
Control 3 EC	0.097%	16:10S	34.0°C	*** TEST PASSED ***
Control 3 IR	0.099%	16:10S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	16:11S		

All tests within acceptable tolerance.


On this date, I installed the above indicated "NEW SOLUTION" in accordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Changed By:

Last Name: BRESNEN

First Name: JOHN

MI: A

Signature: 

Badge No.: 531

Date: 03/25/2005

Calibrating Unit New Standard Solution Report

Equipment

Alcotest 7110 MKIII-C		Serial No.: ARTL-0005
Location: PLAINSBORO TOWNSHIP PD		
Calibration File No.: 00005	Calib. Date: 01/05/2005	Calib. No.: 00002
Certification File No.: 00006	Cert. Date: 01/05/2005	Cert. No.: 00001
Linearity File No.: 00007	Lin. Date: 01/05/2005	Lin. No.: 00001
Solution File No.: 00035	Soln. Date: 04/21/2005	Soln. No.: 00006
Sequential File No.: 00035	File Date: 04/21/2005	

Calibrating Unit: WET	Model No.: CU-34	Serial No.: DDUF S3-0064
Control Solution %: 0.100%		Expires: 11/13/2006
Solution Control Lot: 04K008		Bottle No.: 0857

Function	Result	Time	Temperature	Comment(s)
	%BAC	HH:MM	Simulator (°C)	or Error(s)
Ambient Air Blank	0.000%	15:33D		
Control 1 EC	0.099%	15:33D	34.0°C	*** TEST PASSED ***
Control 1 IR	0.099%	15:33D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	15:34D		
Control 2 EC	0.097%	15:35D	34.0°C	*** TEST PASSED ***
Control 2 IR	0.099%	15:35D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	15:36D		
Control 3 EC	0.098%	15:36D	34.0°C	*** TEST PASSED ***
Control 3 IR	0.099%	15:36D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	15:37D		

All tests within acceptable tolerance.

On this date, I installed the above indicated "NEW SOLUTION" in accordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Changed By:

Last Name: BRESNEN

First Name: JOHN

MI: A

Signature: *John J. Bresnen*

Badge No.: 531

Date: 04/21/2005

Calibrating Unit New Standard Solution Report

Equipment	Alcotest 7110 MKIII-C	Serial: ARTL-0005
Location:	PLAINSBORO TOWNSHIP PD	
Calibration File No.:	00005	Calib. Date: 01/05/2005
Certification File No.:	00006	Calib. No.: 00002
Linearity File No.:	00007	Cert. Date: 01/05/2005
Solution File No.:	00044	Cert. No.: 00001
Sequential File No.:	00044	Lin. Date: 01/05/2005
		Lin. No.: 00001
		Soln. Date: 05/19/2005
		Soln. No.: 00007
		File Date: 05/19/2005
Calibrating Unit:	WET	
Control Solution %:	0.100%	Model No.: CU-34
Solution Control Lot:	04K008	Serial No.: DDUF S3-0064
		Expires: 11/13/2006
		Bottle No.: 0863

Function	Result	Time	Temperature	Comment(s)
	%BAC	HH:MM	Simulator (°C)	or Error(s)
Ambient Air Blank	0.000%	11:55D		
Control 1 EC	0.099%	11:56D	34.0°C	*** TEST PASSED ***
Control 1 IR	0.099%	11:56D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	11:56D		
Control 2 EC	0.097%	11:57D	34.0°C	*** TEST PASSED ***
Control 2 IR	0.098%	11:57D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	11:58D		
Control 3 EC	0.097%	11:58D	34.0°C	*** TEST PASSED ***
Control 3 IR	0.098%	11:58D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	11:59D		

All tests within acceptable tolerance.

On this date, I installed the above indicated "NEW SOLUTION" in accordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Changed By:

Last Name: BRESNEN

First Name: JOHN

MI: A

Signature:

John J. Bresnen

Badge No.: 531

Date: 05/19/2005

Calibrating Unit New Standard Solution Report

Equipment

Location: Alcotest 7110 MKIII-C
PLAINSBORO TOWNSHIP PD

Serial No.: ARTL-0005

Calibration File No.: 00005

Calib. Date: 01/05/2005

Calib. No.: 00002

Certification File No.: 00006

Cert. Date: 01/05/2005

Cert. No.: 00001

Linearity File No.: 00007

Lin. Date: 01/05/2005

Lin. No.: 00001

Solution File No.: 00056

Soln. Date: 06/16/2005

Soln. No.: 00008

Sequential File No.: 00056

File Date: 06/16/2005

Calibrating Unit: WET

Model No.: CU-34

Serial No.: DDUF S3-0065

Control Solution %: 0.100%

Expires: 11/13/2006

Solution Control Lot: 04K008

Bottle No.: 0872

Function	Result	Time	Temperature	Comment(s)
	%BAC	HH:MM	Simulator (°C)	or Error(s)
Ambient Air Blank	0.000%	15:31D		
Control 1 EC	0.099%	15:32D	34.0°C	*** TEST PASSED ***
Control 1 IR	0.098%	15:32D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	15:32D		
Control 2 EC	0.097%	15:33D	34.0°C	*** TEST PASSED ***
Control 2 IR	0.099%	15:33D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	15:34D		
Control 3 EC	0.097%	15:34D	34.0°C	*** TEST PASSED ***
Control 3 IR	0.098%	15:34D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	15:35D		

All tests within acceptable tolerance.

On this date, I installed the above indicated "NEW SOLUTION" in accordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.


Changed By:

Last Name: BRESNEN

First Name: JOHN

MI: A

Signature:



Badge No.: 531

Date: 06/16/2005

Calibrating Unit

New Standard Solution Report

Equipment

Alcotest 7110 MKIII-C
Location: PLAINSBORO TOWNSHIP PD
Serial No.: ARTL-0005
Calibration File No.: 00005
Calib. Date: 01/05/2005
Calib. No.: 00002
Certification File No.: 00006
Cert. Date: 01/05/2005
Cert. No.: 00001
Linearity File No.: 00007
Lin. Date: 01/05/2005
Lin. No.: 00001
Solution File No.: 00064
Soln. Date: 06/28/2005
Soln. No.: 00009
Sequential File No.: 00064
File Date: 06/28/2005

Calibrating Unit: WET
Control Solution %: 0.100%
Solution Control Lot: 04K008
Model No.: CU-34
Serial No.: DDUF S3-0064
Expires: 11/13/2006
Bottle No.: 0862

Function	Result %BAC	Time HH:MM	Temperature Simulator (°C)	Comment(s) or Error(s)
Ambient Air Blank	0.000%	21:26D		
Control 1 EC	-.---%	21:27D	N/A	SIMULATOR TEMP. ERROR
Control 1 IR	-.---%	21:27D	N/A	SIMULATOR TEMP. ERROR
Ambient Air Blank	-.---%	--:--		
Control 2 EC	-.---%	--:--	N/A	
Control 2 IR	-.---%	--:--	N/A	
Ambient Air Blank	-.---%	--:--		
Control 3 EC	-.---%	--:--	N/A	
Control 3 IR	-.---%	--:--	N/A	
Ambient Air Blank	-.---%	--:--		

Test results are not within acceptable range.

On this date, I installed the above indicated "NEW SOLUTION" in accordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Changed By:

Last Name: BRESNEN

First Name: JOHN

MI: A

Signature: 

Badge No.: 531

Date: 06/28/2005

Calibrating Unit

New Standard Solution Report

Equipment

Alcotest 7110 MKIII-C
Location: PLAINSBORO TOWNSHIP PD
Serial No.: ARTL-0005
Calibration File No.: 00005
Calib. Date: 01/05/2005
Calib. No.: 00002
Certification File No.: 00006
Cert. Date: 01/05/2005
Cert. No.: 00001
Linearity File No.: 00007
Lin. Date: 01/05/2005
Lin. No.: 00001
Solution File No.: 00065
Soln. Date: 06/28/2005
Soln. No.: 00010
Sequential File No.: 00065
File Date: 06/28/2005

Calibrating Unit: WET
Control Solution %: 0.100%
Solution Control Lot: 04K008
Model No.: CU-34
Serial No.: DDUF S3-0064
Expires: 11/13/2006
Bottle No.: 0862

Function	Result %BAC	Time HH:MM	Temperature Simulator (°C)	Comment(s) or Error(s)
Ambient Air Blank	0.000%	22:33D		
Control 1 EC	----%	22:34D	34.0°C	CTRL GAS SUPPLY
Control 1 IR	----%	22:34D	34.0°C	CTRL GAS SUPPLY
Ambient Air Blank	----%	--:--		
Control 2 EC	----%	--:--	N/A	
Control 2 IR	----%	--:--	N/A	
Ambient Air Blank	----%	--:--		
Control 3 EC	----%	--:--	N/A	
Control 3 IR	----%	--:--	N/A	
Ambient Air Blank	----%	--:--		

Test results are not within acceptable range.

On this date, I installed the above indicated "NEW SOLUTION" in accordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Changed By:

Last Name: BRESNEN

First Name: JOHN

MI: A

Signature: 

Badge No.: 531

Date: 06/28/2005

Calibrating Unit

New Standard Solution Report

Equipment Alcotest 7110 MKIII-C Serial No.: ARTL-0005
Location: PLAINSBORO TOWNSHIP PD
Calibration File No.: 00005 Calib. Date: 01/05/2005 Calib. No.: 00002
Certification File No.: 00006 Cert. Date: 01/05/2005 Cert. No.: 00001
Linearity File No.: 00007 Lin. Date: 01/05/2005 Lin. No.: 00001
Solution File No.: 00066 Soln. Date: 06/28/2005 Soln. No.: 00011
Sequential File No.: 00066 File Date: 06/28/2005

Calibrating Unit: WET Model No.: CU-34 Serial No.: DDUF S3-0064
Control Solution %: 0.100% Expires: 11/13/2006
Solution Control Lot: 04K008 Bottle No.: 0862

Function	Result %BAC	Time HH:MM	Temperature Simulator (°C)	Comment(s) or Error(s)
Ambient Air Blank	0.000%	23:46D		
Control 1 EC	0.098%	23:46D	34.0°C	*** TEST PASSED ***
Control 1 IR	0.097%	23:46D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	23:47D		
Control 2 EC	0.097%	23:47D	34.0°C	*** TEST PASSED ***
Control 2 IR	0.098%	23:47D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	23:48D		
Control 3 EC	0.097%	23:49D	34.0°C	*** TEST PASSED ***
Control 3 IR	0.099%	23:49D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	23:49D		

All tests within acceptable tolerance.


On this date, I installed the above indicated "NEW SOLUTION" in accordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Changed By:

Last Name: BRESNEN

First Name: JOHN

MI: A

Signature: 

Badge No.: 531

Date: 06/28/2005

Calibrating Unit

New Standard Solution Report

Equipment

Alcotest 7110 MKIII-C
Location: PLAINSBORO TOWNSHIP PD
Calibration File No.: 00067
Certification File No.: 00068
Linearity File No.: 00069
Solution File No.: 00070
Sequential File No.: 00070

Serial No.: ARTL-0005

Calib. Date: 06/29/2005
Cert. Date: 06/29/2005
Lin. Date: 06/29/2005
Soln. Date: 06/29/2005
File Date: 06/29/2005

Calib. No.: 00003
Cert. No.: 00002
Lin. No.: 00002
Soln. No.: 00012

Calibrating Unit: WET
Control Solution %: 0.100%
Solution Control Lot: 04K008

Model No.: CU-34

Serial No.: DDUF S3-0064
Expires: 11/13/2006
Bottle No.: 0865

Function	Result %BAC	Time HH:MM	Temperature Simulator (°C)	Comment(s) or Error(s)
Ambient Air Blank	0.000%	15:59D		
Control 1 EC	0.100%	15:59D	34.0°C	*** TEST PASSED ***
Control 1 IR	0.101%	15:59D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	16:00D		
Control 2 EC	0.099%	16:00D	34.0°C	*** TEST PASSED ***
Control 2 IR	0.099%	16:00D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	16:01D		
Control 3 EC	0.099%	16:02D	34.0°C	*** TEST PASSED ***
Control 3 IR	0.099%	16:02D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	16:02D		

All tests within acceptable tolerance.

On this date, I installed the above indicated "NEW SOLUTION" in accordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Changed By:

Last Name: RUSSO

First Name: MATTEO

MI: B

Signature: _____



Badge No.: 5204

Date: 06/29/2005

Calibrating Unit

New Standard Solution Report

Equipment	Alcotest 7110 MKIII-C	Serial No.: ARTL-0005
Location:	PLAINSBORO TOWNSHIP PD	
Calibration File No.:	00067	Calib. Date: 06/29/2005
Certification File No.:	00068	Calib. No.: 00003
Linearity File No.:	00069	Cert. Date: 06/29/2005
Solution File No.:	00085	Cert. No.: 00002
Sequential File No.:	00085	Lin. Date: 06/29/2005
		Lin. No.: 00002
		Soln. Date: 07/26/2005
		Soln. No.: 00013
		File Date: 07/26/2005
Calibrating Unit:	WET	
Control Solution %:	0.100%	Model No.: CU-34
Solution Control Lot:	04K008	Serial No.: DDUF S3-0064
		Expires: 11/13/2006
		Bottle No.: 0867

Function	Result	Time	Temperature	Comment(s)
	%BAC	HH:MM	Simulator (°C)	or Error(s)
Ambient Air Blank	0.000%	22:01D		
Control 1 EC	0.100%	22:01D	34.0°C	*** TEST PASSED ***
Control 1 IR	0.099%	22:01D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	22:02D		
Control 2 EC	0.099%	22:02D	34.0°C	*** TEST PASSED ***
Control 2 IR	0.100%	22:02D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	22:03D		
Control 3 EC	0.099%	22:04D	34.0°C	*** TEST PASSED ***
Control 3 IR	0.099%	22:04D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	22:04D		

All tests within acceptable tolerance.

On this date, I installed the above indicated "NEW SOLUTION" in accordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Changed By:

Last Name: BRESNEN

First Name: JOHN

MI: A

Signature:



Badge No.: 531

Date: 07/26/2005

Calibrating Unit New Standard Solution Report

Equipment	Alcotest 7110 MKIII-C	Serial No.:	ARTL-0005
Location:	PLAINSBORO TOWNSHIP PD		
Calibration File No.:	00067	Calib. Date:	06/29/2005
Certification File No.:	00068	Cert. Date:	06/29/2005
Linearity File No.:	00069	Lin. Date:	06/29/2005
Solution File No.:	00095	Soln. Date:	08/23/2005
Sequential File No.:	00095	File Date:	08/23/2005
Calibrating Unit:	WET	Model No.:	CU-34
Control Solution %:	0.100%	Serial No.:	DDUF S3-0064
Solution Control Lot:	04K008	Expires:	11/13/2006
		Bottle No.:	0868

Function	Result %BAC	Time HH:MM	Temperature Simulator (°C)	Comment(s) or Error(s)
Ambient Air Blank	0.000%	15:08D		
Control 1 EC	0.100%	15:09D	34.0°C	*** TEST PASSED ***
Control 1 IR	0.099%	15:09D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	15:10D		
Control 2 EC	0.099%	15:10D	34.0°C	*** TEST PASSED ***
Control 2 IR	0.100%	15:10D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	15:11D		
Control 3 EC	0.099%	15:12D	34.0°C	*** TEST PASSED ***
Control 3 IR	0.099%	15:12D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	15:12D		

All tests within acceptable tolerance.

On this date, I installed the above indicated "NEW SOLUTION" in accordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Changed By:

Last Name: BRESNEN

First Name: JOHN

MI: A

Signature: 

Badge No.: 531

Date: 08/23/2005

Calibrating Unit

New Standard Solution Report

Equipment Alcotest 7110 MKIII-C Serial No.: ARTL-0005
Location: PLAINSBORO TOWNSHIP PD
Calibration File No.: 00067 **Calib. Date:** 06/29/2005 **Calib. No.:** 00003
Certification File No.: 00068 **Cert. Date:** 06/29/2005 **Cert. No.:** 00002
Linearity File No.: 00069 **Lin. Date:** 06/29/2005 **Lin. No.:** 00002
Solution File No.: 00106 **Soln. Date:** 09/20/2005 **Soln. No.:** 00015
Sequential File No.: 00106 **File Date:** 09/20/2005

Calibrating Unit: WET **Model No.:** CU-34 **Serial No.:** DDUF S3-0064
Control Solution %: 0.100% **Expires:** 11/13/2006
Solution Control Lot: 04K008 **Bottle No.:** 0870

Function	Result %BAC	Time HH:MM	Temperature Simulator (°C)	Comment(s) or Error(s)
Ambient Air Blank	0.000%	14:22D		
Control 1 EC	0.100%	14:23D	34.0°C	*** TEST PASSED ***
Control 1 IR	0.100%	14:23D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	14:23D		
Control 2 EC	0.098%	14:24D	34.0°C	*** TEST PASSED ***
Control 2 IR	0.099%	14:24D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	14:24D		
Control 3 EC	0.099%	14:25D	34.0°C	*** TEST PASSED ***
Control 3 IR	0.101%	14:25D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	14:26D		

All tests within acceptable tolerance.

On this date, I installed the above indicated "NEW SOLUTION" in accordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Changed By:

Last Name: BRESNEN

First Name: JOHN

MI: A

Signature: *John J. Bresnen*

Badge No.: 531

Date: 09/20/2005

Calibrating Unit

New Standard Solution Report

Equipment: Alcotest 7110 MKIII-C
Location: PLAINSBORO TOWNSHIP PD
Serial No.: ARTL-0005
Calibration File No.: 00067
Calib. Date: 06/29/2005
Calib. No.: 00003
Certification File No.: 00068
Cert. Date: 06/29/2005
Cert. No.: 00002
Linearity File No.: 00069
Lin. Date: 06/29/2005
Lin. No.: 00002
Solution File No.: 00112
Soln. Date: 10/14/2005
Soln. No.: 00016
Sequential File No.: 00112
File Date: 10/14/2005

Calibrating Unit: WET
Control Solution %: 0.100%
Solution Control Lot: 04K008
Model No.: CU-34
Serial No.: DDUF S3-0064
Expires: 11/13/2006
Bottle No.: 0861

Function	Result %BAC	Time HH:MM	Temperature Simulator (°C)	Comment(s) or Error(s)
Ambient Air Blank	0.000%	14:56D		
Control 1 EC	0.100%	14:56D	34.0°C	*** TEST PASSED ***
Control 1 IR	0.099%	14:56D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	14:57D		
Control 2 EC	0.098%	14:58D	34.0°C	*** TEST PASSED ***
Control 2 IR	0.099%	14:58D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	14:58D		
Control 3 EC	0.098%	14:59D	34.0°C	*** TEST PASSED ***
Control 3 IR	0.099%	14:59D	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	15:00D		

All tests within acceptable tolerance.

On this date, I installed the above indicated "NEW SOLUTION" in accordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Changed By:

Last Name: BRESNEN

First Name: JOHN

MI: A

Signature:

John A. Bresnen

Badge No.: 531

Date: 10/14/2005

Calibrating Unit

New Standard Solution Report

Equipment Alcotest 7110 MKIII-C Serial No.: ARTL-0005
Location: PLAINSBORO TOWNSHIP PD
Calibration File No.: 00067 **Calib. Date:** 06/29/2005 **Calib. No.:** 00003
Certification File No.: 00068 **Cert. Date:** 06/29/2005 **Cert. No.:** 00002
Linearity File No.: 00069 **Lin. Date:** 06/29/2005 **Lin. No.:** 00002
Solution File No.: 00117 **Soln. Date:** 11/10/2005 **Soln. No.:** 00017
Sequential File No.: 00117 **File Date:** 11/10/2005

Calibrating Unit: WET **Model No.:** CU-34 **Serial No.:** DDUF S3-0064
Control Solution %: 0.100% **Expires:** 11/13/2006
Solution Control Lot: 04K008 **Bottle No.:** 0858

Function	Result %BAC	Time HH:MM	Temperature Simulator (°C)	Comment(s) or Error(s)
Ambient Air Blank	0.000%	17:11S		
Control 1 EC	0.100%	17:12S	34.0°C	*** TEST PASSED ***
Control 1 IR	0.100%	17:12S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	17:12S		
Control 2 EC	0.097%	17:13S	34.0°C	*** TEST PASSED ***
Control 2 IR	0.099%	17:13S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	17:14S		
Control 3 EC	0.098%	17:14S	34.0°C	*** TEST PASSED ***
Control 3 IR	0.099%	17:14S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	17:15S		

All tests within acceptable tolerance.

On this date, I installed the above indicated "NEW SOLUTION" in accordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Changed By:

Last Name: BRESNEN

First Name: JOHN

MI: A

Signature: *John J. Bresnen*

Badge No.: 531

Date: 11/10/2005

Calibrating Unit

New Standard Solution Report

Equipment

Alcotest 7110 MKIII-C
Location: PLAINSBORO TOWNSHIP PD
Serial No.: ARTL-0005
Calibration File No.: 00067
Calib. Date: 06/29/2005
Calib. No.: 00003
Certification File No.: 00068
Cert. Date: 06/29/2005
Cert. No.: 00002
Linearity File No.: 00069
Lin. Date: 06/29/2005
Lin. No.: 00002
Solution File No.: 00128
Soln. Date: 12/02/2005
Soln. No.: 00018
Sequential File No.: 00128
File Date: 12/02/2005

Calibrating Unit: WET
Control Solution %: 0.100%
Solution Control Lot: 04K008
Model No.: CU-34
Serial No.: DDUF S3-0064
Expires: 11/13/2006
Bottle No.: 0864

Function	Result %BAC	Time HH:MM	Temperature Simulator (°C)	Comment(s) or Error(s)
Ambient Air Blank	0.000%	05:13S		
Control 1 EC	0.099%	05:14S	34.0°C	*** TEST PASSED ***
Control 1 IR	0.100%	05:14S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	05:15S		
Control 2 EC	0.097%	05:15S	34.0°C	*** TEST PASSED ***
Control 2 IR	0.099%	05:15S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	05:16S		
Control 3 EC	0.096%	05:17S	34.0°C	*** TEST PASSED ***
Control 3 IR	0.099%	05:17S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	05:18S		

All tests within acceptable tolerance.


On this date, I installed the above indicated "NEW SOLUTION" in accordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Changed By:

Last Name: PROCACCINI

First Name: NICK

MI: -

Signature: 

Badge No.: 23

Date: 12/02/2005

Calibrating Unit

New Standard Solution Report

Equipment

Alcotest 7110 MKIII-C
Location: PLAINSBORO TOWNSHIP PD
Serial No.: ARTL-0005
Calibration File No.: 00067
Calib. Date: 06/29/2005
Calib. No.: 00003
Certification File No.: 00068
Cert. Date: 06/29/2005
Cert. No.: 00002
Linearity File No.: 00069
Lin. Date: 06/29/2005
Lin. No.: 00002
Solution File No.: 00131
Soln. Date: 12/02/2005
Soln. No.: 00019
Sequential File No.: 00131
File Date: 12/02/2005

Calibrating Unit: WET
Control Solution %: 0.100%
Solution Control Lot: 04K008
Model No.: CU-34
Serial No.: DDUF S3-0064
Expires: 11/13/2006
Bottle No.: 0874

Function	Result	Time	Temperature	Comment(s)
	%BAC	HH:MM	Simulator (°C)	or Error(s)
Ambient Air Blank	0.000%	21:40S		
Control 1 EC	0.099%	21:41S	34.0°C	*** TEST PASSED ***
Control 1 IR	0.100%	21:41S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	21:42S		
Control 2 EC	0.096%	21:42S	34.0°C	*** TEST PASSED ***
Control 2 IR	0.101%	21:42S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	21:43S		
Control 3 EC	0.097%	21:44S	34.0°C	*** TEST PASSED ***
Control 3 IR	0.100%	21:44S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	21:44S		

All tests within acceptable tolerance.

On this date, I installed the above indicated "NEW SOLUTION" in accordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Changed By:

Last Name: BRESNEN

First Name: JOHN

MI: A

Signature:



Badge No.: 531

Date: 12/02/2005

Calibrating Unit

New Standard Solution Report

Equipment Alcotest 7110 MKIII-C Serial No.: ARTL-0005
Location: PLAINSBORO TOWNSHIP PD
Calibration File No.: 00067 **Calib. Date:** 06/29/2005 **Calib. No.:** 00003
Certification File No.: 00068 **Cert. Date:** 06/29/2005 **Cert. No.:** 00002
Linearity File No.: 00069 **Lin. Date:** 06/29/2005 **Lin. No.:** 00002
Solution File No.: 00142 **Soln. Date:** 12/17/2005 **Soln. No.:** 00020
Sequential File No.: 00142 **File Date:** 12/17/2005

Calibrating Unit: WET **Model No.:** CU-34 **Serial No.:** DDUF S3-0064
Control Solution %: 0.100% **Expires:** 11/13/2006
Solution Control Lot: 04K008 **Bottle No.:** 0869

Function	Result %BAC	Time HH:MM	Temperature Simulator (°C)	Comment(s) or Error(s)
Ambient Air Blank	0.000%	06:54S		
Control 1 EC	0.100%	06:54S	34.0°C	*** TEST PASSED ***
Control 1 IR	0.100%	06:54S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	06:55S		
Control 2 EC	0.098%	06:56S	34.0°C	*** TEST PASSED ***
Control 2 IR	0.098%	06:56S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	06:57S		
Control 3 EC	0.098%	06:57S	34.0°C	*** TEST PASSED ***
Control 3 IR	0.099%	06:57S	34.0°C	*** TEST PASSED ***
Ambient Air Blank	0.000%	06:58S		

All tests within acceptable tolerance.

On this date, I installed the above indicated "NEW SOLUTION" in accordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Changed By:

Last Name: BRESNEN

First Name: JOHN

MI: A

Signature: 

Badge No.: 531

Date: 12/17/2005